




HTL SMALL ELECTRONIC WARNING SIGN

Model: MV SEWS

Operation & Maintenance Manual

Version 1.1



Index

| | |
|---------------------------------------|---|
| 1. Health and Safety | 3 |
| 2. General Overview | 4 |
| 2.1. Cabinet Specifications | 4 |
| 2.2. Optical Characteristics | 5 |
| 2.3. Electrical Characteristics | 5 |
| 2.4. Major Components..... | 5 |
| 3. Maintenance Guide | 7 |
| 3.1. Maintenance Tool List..... | 7 |
| 3.3. Cabinet Maintenance | 8 |
| 4. Troubleshooting | 8 |

| Release / Change | Version | Release Date |
|------------------|---------|--------------|
| Initial Release | 1.0 | July 2023 |
| Layout Update | 1.1 | Nov 2024 |
| | | |
| | | |
| | | |

Safety Instructions



WARNING: Ensure all safety instructions have been followed prior to servicing.



WARNING: Ensure that no items fall onto the lanes below at any time.



CAUTION: When the door/cover of the equipment is opened, please ensure it is fixed before performing next procedure. After finishing maintenance, ensure the door/cover is locked.



CAUTION: The LEDs on LED Module of the equipment are ESD (Electro-Static Discharge) sensitive. Take necessary precautions to prevent damage to the LED.

1. Health and Safety

All personnel involved in carrying out the work must be aware of any site working regulations and required certification.

Before taking any installation or maintenance action, service personal must follow the above safe working practices:

- Only allow sufficiently experienced personnel to do maintenance.
- Provide sufficient illumination for the job, especially during non-daylight hours.
- Wear personal protective gear when working near or with energized parts.
- Use insulated tools and equipment when working near or with energized parts.
- Take measures to avoid inadvertent contact of conductive materials or equipment with energized parts of VMS

WARNING

The VMS is a 12 VDC device. Harding Traffic cannot guarantee that mains power may not have been introduced as part of the installation e.g. 230VAC: 12VDC Power Supply.

Service Personal must ensure that the system is suitably isolated before working on the VMS.


CAUTION – HEAVY EQUIPMENT

The VMS should be adequately supported during installation, replacement or maintenance. All lifting and moving jobs must be performed by mobile crane or other suitable lifting device.

2. General Overview

2.1. Cabinet Specifications

| | |
|----------------------------|--|
| Cabinet height: | 888mm |
| Cabinet width: | 888mm |
| Cabinet thickness: | 180mm |
| Weight: | 27kg without Batteries |
| Cabinet Material: | Aluminium |
| Paint Colour: | Front – Matt Black Rear – Aircraft Grey |
| Maintenance method: | Front Access |
| Pixel Pitch: | P16 |



2.2. Optical Characteristics

| | | |
|-----------------|---------|-------------------|
| Luminance | EN12966 | L3 |
| Luminance ratio | EN12966 | R3 |
| Colour | EN12966 | C2 |
| Beam width | EN12966 | (H: 30°, V: -10°) |


2.3. Electrical Characteristics

| | |
|-------------------------------|------------|
| Power supply | 12V/24V DC |
| Power consumption (Max)* | 50W |
| Power consumption (Average) | 20W |
| Internal voltage - LED boards | 4.2VDC |
| Internal voltage - Controller | 5VDC |

*Max power consumption is only ever achieved within a manually initiated test. Max power is with all LED's on, in white and manually set to full brightness.



2.4. Major Components

2.4.1 CPU / Controller Card – 9281/9291



| No. | Name | Description |
|-----|---|--|
| 1 | Network interface-RJ45 | Ethernet interface for major network |
| 2 | Radar RS232+RS485 PORT | RS232/RS48 port for customer to self-define CZ9291, switch P1 to choose RS232 or RS485 |
| 3 | PC RS232+RS485 PORT | RS232/RS48 port for Customer to self-define CZ9281, switch P2 to choose RS232 or RS485 |
| 4 | Power port | To connect with 4.6V-26V power input |
| 5 | 8 output control port | To control wigwag |
| 6 | Extended RS485 port | For additional device |
| 7 | LED panel port | Connect to the LED Panel (EN port) |
| 8 | External voltage signal isolation input | HGND: External voltage IN1-8:voltage input |
| 9 | Light sensor port | To connect with environment light sensors; two can be connected. |
| 10 | Hub board port | Supply 5V power and GND, the max output 7.5W |






2.4.2 Other components



| CODE | DESCRIPTION |
|-----------|---|
| MV 3551 | LED TILE / PCB BOARD P16 8*16 |
| MV 9291D | VMS CPU/MOTHER BOARD (JETFILE) |
| MV 1698 | IMPOSA BATTERY DISCHARGE 12V/24V 110-7412 |
| MV 9140E | SOLAR CHARGER 12/24V IMPOSA 110-7403 |
| MV LTK1DS | CABINET DOOR SWITCH LTK-1 (ITS-02-01) |

3. Maintenance Guide

3.1. Maintenance Tool List

| Maintenance Tool List | | | |
|-----------------------|---------------------------|----------|--|
| Item | Tool | Quantity | Remarks |
| 1. | Torx screwdriver | 1 |  |
| 2. | Long Phillips screwdriver | 1 |  |
| 3. | Slotted screwdriver | 1 |  |
| 4. | Multimeter | 1 |  |
| 5 | Cabinet Keys | 1 |  |

3.2. Preventative Maintenance

To ensure the continued optimal performance and longevity of your VMS in challenging environments, regular preventive maintenance is recommended. By following these guidelines, you can mitigate potential issues and extend the lifespan of your product:

Cleaning Schedule: Establish a routine cleaning schedule based on the local conditions and usage. While the standard recommendation is maintenance every six months, consider more frequent cleaning if the environment is particularly harsh.

Cabinet Maintenance:

- a. Employ a pressure cleaner to clean the rear of the cabinet, removing accumulated dirt and grime.
- b. Regularly check the cabinet's interior. Evaluate the operational status and address any anomalies promptly.

Record Keeping: Maintain a record of maintenance activities, including dates, procedures performed, and observations made. This documentation can help track the product's health and guide future maintenance decisions.

Professional Inspection: Periodically, consider engaging professional technicians to conduct a thorough inspection of the VMS. Their expertise can identify potential issues that might not be apparent during routine maintenance.

| Faults | Action |
|---|---|
| Check for marks, scratches, dirt, or cracks | Use an appropriate cleaning solution to remove any visible marks or dirt. |
| Verify if the lights are receiving on/off commands from the control/battery box | If not, report the fault to Harding Traffic Ltd. |
| Ensure door locks are secured and check for any broken parts | If loose or broken, use the correct key to lock it securely by turning clockwise or replace any broken parts. |

| | |
|--|---|
| Check that all cable glands are securely fastened. | If any are loose, press the gland back in place and ensure they are securely connected. |
| Inspect the solar panel for dirt or debris | Clean the panel using a suitable cleaning solution if it appears dirty or obstructed. |

3.3. Cabinet Maintenance

Because of its ability to withstand extremely harsh environments, the VMS requires minimal maintenance. However, regular maintenance can help prolong the product's lifespan and ensure optimal display performance.

The suggested maintenance interval is every six months, although this duration can be adapted based on the local conditions.

Maintenance tool:

- Gentle non-woven fabric or a soft brush
 - Neutral cleaning solution (non-abrasive)
- Basic maintenance equipment

Recommended Maintenance Procedure

- 1) Moisten a cloth with the cleaning solution, then use it to gently wipe away dust from the display surface. Rinse the surface with water afterwards.
- 2) The back of the cabinet can also be cleaned using a pressure cleaner.

Following the VMS wash, open the door to inspect and assess the operational status within the cabinet.

4. Troubleshooting

| Item | Description | Solution |
|---------------------------|---|---|
| No Display | VMS does not respond and cannot be lit | 1. Check power supply: <ul style="list-style-type: none"> • Check Connections • Check Input Voltage • Check inputs |
| | Unexpected images | 1. Picture overlap, part of the picture is missing, screen position shift etc, please contact Harding Traffic |
| | Tile/s failure including LED is always on, bright / dim, flashing or color patches | One module display is not working or has abnormal brightness: <ul style="list-style-type: none"> • Check power cable for the module • Check Signal Cable for the module • Swap module with another to determine if the fault is related to the input or elsewhere Multiple modules are not working or have abnormal brightness <ul style="list-style-type: none"> • Check the power supply to the modules |
| Functional problem | Optical sensor problem | <ul style="list-style-type: none"> • Check whether the Optical sensor connector is reliably connected to the CPU / Controller Card • Check whether the Optical Sensor wire is damaged |

| | | |
|--|---------------------------|---|
| | | <ul style="list-style-type: none"> • Swap with another light sensor to confirm whether the issue is with the sensor or elsewhere |
| | <p>Door sensor</p> | <ul style="list-style-type: none"> • Check whether the door switch connector is reliably connected to the CPU / Controller Card • Check if the contact of the door sensor is operating (normally open – closes when door is shut) • Swap with another door switch to confirm whether the issue is with the sensor or elsewhere • If the above method still cannot solve the problem, please contact the manufacturer's professional and technical personnel for handling. |

In all other cases, please contact Harding Traffic on 0800 427 346 or at service@hardingtraffic.co.nz